

Hinweise zum Betrieb der CTFWIKE-2 Tastatur

- Installieren Sie die Treiber von der TreiberCD (auch unter Windows XP).
- Der linke Mausbutton befindet sich auf der Rückseite links, der rechte Mausbutton befindet sich auf der Rückseite rechts
- Anders als im Handbuch beschrieben funktioniert die Inbetriebnahme wie folgt :
 - 1.) USB Dongle mit PC verbinden und „Connect“-Taste drücken
Dann :
 - 2.) „Connect“-Taste auf Tastatur drücken.
- Falls Tasten auf der rechten Seite Zahlen statt Buchstaben ausgeben, drücken Sie die NUMLOCK-Taste.

Hints for operating CTFWIKE-2 keyboard

- Install the drivers from the included Driver CD (even on Windows XP).
- The left mouse button is located on the keyboard's rear side on the left side, the right mouse button is located on the keyboard's rear side on the right side.
- Otherwise than noted in the manual, the installation is handled like this :
 - 1.) Connect USB dongle with PC and press „Connect“-button
Then :
 - 2.) Press „Connect“-button on keyboard.
- If you get numbers instead of letters when pressing buttons on the right side, then press the NUMLOCK-key first.